

NOTES:

- 1) TRIM "OV" ONLY.
- 2) TRIM RD, SQ ONLY.
- 3) STRIKEPLATE AREA TO BE RECESSED 4.0mm [.156] DEEP.
- 4) POSITION STRIKE PLATE INTO CAVITY AND MARK MOUNTING HOLES WITH PUNCH. REMOVE AND DRILL.
- 5) ALTERNATE BACKSET DIMENSION IS 60.0mm OR 2.375".

Description:
OV-RD-SQ, SL2 SERIES DOOR PREP

TOLERANCES UNLESS OTHERWISE SPECIFIED:
X.X (METRIC)= ±0.5
X.XX(METRIC)= ±0.15
0.00"(UNIFIED)= ±.015"
0.000"(UNIFIED)= ±.005"

Drawing No:
DP-215

Drawn By: **JWB**

Orig.Date **12-19-14**

Rev. Date:

Rev.:



STRIKE PLATE PREPARATION

(3-1/2" STANDARD STRIKE)

OVAL-ROUND-SQUARE TRIM INSTALLATION

